

## **ARTSORPTION Installation Guide**

Artsorption acoustic wall panels can be painted before or after they are installed. However, if they are painted prior to fixing, please ensure the paint is fully dry before handling them. Our special aerosol adhesive is used to glue them to most wall surfaces.

The panels and adhesive must be kept and stored inside at room temperature so they acclimatise in the area where they are to be mounted for at least 24 hours before fixing.

White cotton gloves should be used when handling the panels to avoid soiling them. Walls must be clean, flat, level, dry, solid and free from dust, oil, grease and any other contaminant that may affect the adhesion. We recommend the adhesive is used in temperatures of around 21OC and in well ventilated conditions.

The adhesive comes in easy to use aerosol cans and is applied to both surfaces and an immediate bond is obtained when they two surfaces are pressed together. More instructions are on the can. Pressure must be applied evenly with the flat of the hands over the entire panel upon contact; care must also be taken not to damage the face of the diffuser by pushing too hard.

We strongly recommend a test adhesion is conducted before proceeding with full installation.

Every effort is made to ensure the information given here is accurate and reliable but is only to be used as a guidance. As each application can be different, users are advised to conduct their own tests to confirm suitability. As our policy is one of continuous development and improvement, we reserve the right to make changes without prior notice.



Tel: 01993 704981

Fax: 01993 779569